

ViewFinder 7.2 Shortcut Keys (Macintosh)

Startup

Hold option key down on startup to use default preferences.

Scan Area

Option-click to go to min/max value.

Resolution

Option-click to go to min/max value.

Line Time

Option-click to go to min/max value.

ISO

Option-click to go to min/max value.

Cmd-click to use 1/3 stop if settings are 1/10 and vice versa.

Shift-click to change by 1 stop.

Insert Direction

Hold option key while selecting direction to make "crop rotates with image" preference do the opposite.

Curve Brightness

Option-click to move curve to maximum left or right position.

Shift-click to move curve by 1 EV.

Curve Contrast

Option-click to have contrast center on Zero-EV location on horizontal scale.

Curve Handles

Option-drag to make smaller adjustments.

Curve EV Scale

Shift-drag to show raw value on horizontal axis.

Histogram

Option-click to normalize.

Control-click to display colored histogram.

Prescan

Option-click Prescan button to load preview from none 14 file.

Automatically finds "PreviewPic.tif" if located in folder with ViewFinder or on desktop, otherwise presents an open dialog.

Option-shift-click overrides automatic loading of "PreviewPic.tif" and presents file open dialog.

Spots

Use delete key to delete individual spots.

Shift-click to select more than one for dragging or deleting.

Drag spots out of image to delete.

Grid and Mask

Control-double-click to display Appearance preferences.

Grid

Control-drag to move grid.

Control-shift-drag to resize grid.

ToneZones™

Control-Command-click to distribute zones evenly.

Control-Option-Command-click to make zones evenly distributed gray scale.

Easter Egg

Option-click on the camera icon in the Better Light logo.